


Country Charm 24”

FOR BEST RESULTS WE RECOMMEND THAT YOU PLACE YOUR GLOWING EMBERS ON THE BURNER BEFORE SETTING UP YOUR LOG SET. SEE THE INSTRUCTION MANUAL THAT WAS SUPPLIED WITH THE BURNER HEARTH KIT.

Step 1. Place back log H-1047.



Step 2. Place left log H-01052.




Country Charm 24”

Step 3. Place right log H-1050



Step 4. Place right front log H-1051. Place logs H-1042 & H-1049.




Country Charm 24"

Step 5. Place log H-1048



Step 6. Place logs H-1056, H-01043 x 2. Place the Pine cone (A-0380) in front of the controls. Place the 2 decorative logs H-1044 & H-1045 on floor in front of burner as shown below.



Country Charm 24"



H-1047



H-1052



H-1051



H-1042



H-1049



H-1050



H-1056

H-1043 x 2



H-1048



H-1044



H-1045



A-0380

3/22/2011

Country Charm 30"

FOR BEST RESULTS WE RECOMMEND THAT YOU PLACE YOUR GLOWING EMBERS ON THE BURNER BEFORE SETTING UP YOUR LOG SET. SEE THE INSTRUCTION MANUAL THAT WAS SUPPLIED WITH THE BURNER HEARTH KIT.

Step 1. Place back log H-1046. Then place front left log H-1036 & front right log H-1037




Step 2. Place log H-1042 & H-1038



Country Charm 30''


Step 3. Place log H-1040 & H-1093



Step 4. Place log H-1041 & H-1039. Place logs H-1044 & H-1045 on floor in front of the burner.



Country Charm 30"



H-1046



H-1036



H-1037



H-1042



H-1040



H-1038



H-1041



H-1043



H-1039



H-1044



H-1045

3/22/2011